
Danair AUTOMATIC HAMMER® Parts Diagram: Models AH-15-PF & AH-15-PF-9000

10 - 24 x 5/8 SCREW 157 CAP 2-031 "O" RING 161 EXHAUST SEAT 162 PLUG 1/4 - 20 x 5/8 SCREW **159 STEM** - 212 "O" RING 163 BUMPER 3 - 127 "O" RING 158 VALVE 3 - 114 "O" RING 160 SLEEVE AS-319 STROKE CONTROL SPACER 156 HOUSING

Model AH-15-GL
***See note below

LIMITED LIFETIME WARRANTY

Any part which is determined by DANAIR to be defective in material or workmanship and returned to DANAIR, Elko, NV, shipping cost prepaid, will be repaired or replaced at DANAIR'S option. This warranty does not apply to normal wear or damage resulting from accident, alteration or use otherwise than recommended by DANAIR. Any liability for consequential and incidental damages is expressly disclaimed. DANAIR'S liability in all events is limited to, and shall not exceed, the purchase price paid for the DANAIR product.



***For Model AH-15-GL the four parts shown below line are replaced with the 300-01 Aluminum Piston and the 5/16-18 x 1-1/2" Screw